

MANUFACTURING PROCESS ALUMINIUM BARRIER FILMS & BAGS

www.browpharmapak.com

Email : production@browpharmapak.com Tel No: +44 (0)28 9079 8171 From ROI : 048 9079 8171






ROLLS ARE LOADED ONTO THE MACHINE TO MAKE SURE THE TWO LAYERS WHICH COME INTO CONTACT ARE THE FILM 5-LLDPE LAYER.


1. AS THIS LAYER COMES INTO CONTACT WITH THE PRODUCT BEING PACKED IT IS CERTIFIED TO BE FOOD GRADE.
2. THIS LAYER IS ALSO THE LAYER THAT SEALS THE TWO SHEETS TOGETHER WHEN HEAT IS APPLIED.

D FINAL POUCH STAGE



3 WELDED SHUT SIDES DEPTH OF WELD LEADS TO INTERNAL & EXTERNAL DIMENSIONS BEING QUOTED.

(E) PACKING, TESTING & SHIPPING STAGE



PRODUCT IS TESTED, PACKED & PALLETED READY TO SHIP.

F FINAL PACKAGING STAGE AT CUSTOMER SIDE

CUSTOMER PACK THEIR PRODUCTS INTO POUCH & SEAL THE OPEN END WITH AUTOMATIC MACHINERY OR WITH MANUAL HEAVY DUTY HAND SEALER WHICH WE CAN SUPPLY. HEAT IS TRANSFERRED ACROSS THE 5 LAYERS TO WELD THE LLDPE CONTACT LAYERS TOGETHER. ALTERNATIVELY CLIP SEAL STRIPS & PRESSURE RELEASE VENTS CAN BE ADDED TO THE POUCHES AS PART OF THE MANUFACTURING PROCESS.